

Beam Loss in the First Segment of the FRIB Linac

R. Shane, S. Cogan, S. M. Lidia, T. Maruta
Facility for Rare Isotope Beams (FRIB), Michigan State University, East Lansing, MI 48824 USA

Loss Monitoring

Why monitor beam loss?

- Assist with tuning
- Minimize activation
- Extend machine lifetime
- Avoid beam damage


Challenges for FRIB

- High beam intensity
- Folded geometry
- Superconducting components

Loss Limits


- High beam intensity means significant damage is possible quickly
- Slow loss limits set primarily by heat load (magnet quenching) and machine degradation, rather than activation of beamline parts

Beam loss (W/m)	Stop beam?	Response time
$P < 1$	No	≥ 1 sec
$1 \leq P < 10$	Yes	1 sec (slow)
$P \geq 10$	Yes	$< 15 \mu\text{s}$ (fast)




Radiation Cross Talk Simulations

Z. Liu, IPAC 2012, MOPPR077



Only 1.5% of dose detected at LS1 is from LS1 losses



Cross talk from LS3 dominates low-energy half of LS2

Devices

Beam Measurements

- Halo monitor rings (HMR)
- Beam current monitors (BCM)

Radiation Measurements

- Ionization chambers (IC)
- Neutron detectors (ND)

Temperature Measurements

- Resistive temperature devices (RTD)

Commissioned

	LS1	FS1	LS2 low energy	LS2 high energy	FS2	LS3	BDS
Fast Loss < 35 ms	DBCM	DBCM	DBCM	DBCM	DBCM	DBCM	DBCM
	HMR	BLM	BLM	BLM	BLM	BLM	BLM
Slow loss 100 ms	HMR/Temp	BLM	BLM	BLM	BLM	BLM	BLM
	HMR/Temp		Temp	DBCM	DBCM	DBCM	DBCM

Distribution

- BCM distributed throughout accelerator
- HMR/Temp important for slow losses in LS1
 - HMR in boxes between cryomodules, RTDs within cryomodules
- BLM important for slow losses in rest of linac
 - ND primarily mounted to outside of cryomodules
 - IC mounted to magnet stands below beamline in folding segments (pairs)

- | Beam Current Monitor (BCM)
- | Halo Monitor Ring (HMR)
- | Neutron Detectors, Ion Chambers

