




### Options for Next Generation Digital Acquisition Systems DIPAC 2011 - Andrea Boccardi
















### The Concept of Carrier/Mezzanine



### The Concept of Carrier/Mezzanine



### The Concept of Carrier/Mezzanine

### Memory


Modulare systems:

Mezzonine
 Make spares management easier
 In conjunction with the use of standards allows using COTS and ease an eventual port to different platforms

3 /17

## FPGA Mezzanine Card

- FMC is VITA 57
- 2 widths: single
  (69mm) and double
  (139mm)
- BGA style connector
- 2 connector
  densities: Low Pin
  Count (160 pins) and
  High Pin Count (400)



## FMC standard


#### Pros:

- Very Flexible: pin function, direction and electrical standard are defined at FPGA configuration time
- Mezzanines can self
  identify via I2C can
  be performed before
  configuring the
  FPGA

### Cons:

- Real Estate
- Little attention paid to Carrier-To-Mezzanine clock distribution

## VME FMC Carrier



## PCIe FMC Carrier



- Designed in parallel to the VFC
- Effort in using the same components on the 2 carriers
- Almost seamless porting of the application code from one carrier to the other with the help of code wrappers  $\frac{7}{17}$

# VME and PCIe comparison

#### **VME64**

- 80MB/s (320 with 2eSST)
- Up to 3 FMC (in 6U format) accessible on the front panel
- Possibility to have RTM
- Up to ~108W per board

### PCIe

- Not a bus but a point to point link
- 250MB/s (PCIe 1.0) per lane (one LVDS pair per direction) and up to 32 lanes
- 1 FMC accessible on the front panel
- 10, 25 or 75W per board

# VME and PCIe comparison

#### **VME64**

- 80MB/s (320 with 2eSST)
- Up to 3 FMC (in 6U format) accessible on the front panel
- Possibility to have RTM
- Up to ~108W per board

### PCIe

- Not a bus but a point to point link
- 250MB/s (PCIe 1.0) per lane (one LVDS pair per direction) and up to 32 lanes
- 1 FMC accessible on the front panel
- 10, 25 or 75W per board

### They both lack board to board fast links

- VXS is VITA-41
- It re-defines the P0 (middle connector) to have 16 differential pairs (10GHz) and 31 reserved pins
- The protocol of the differential pairs is defined by substandards (PCIe, Ethernet are just 2 examples)
- System management based on IPMI (I2C) but only as a recommendation
- Backplane can have star, double-star (both requiring a switch) or mesh topology
- Backward compatible with old VME64 (2esst) boards\*
- Not many ongoing projects

- VXS is VITA-41
- It re-defines the P0 (mid Device or) to have 16 differential pairs (10GHz) and 31 reserved pins
- The protocol of the differential pairs is defined by substandards (PCIe, Ethernet are just 2 examples)
- System management b redeviceation
   SWITCH
   SWITCH
   Device
   Device
- Backplane can have star, double star (both requiring a switch) or mesh topology
- Backward compatible with old VME64 (2esst) boards\*
- Not many ongoing proje Device


- VXS is VITA-41
- It re-defines the P0 (mid Devicetor) to have 16 differential pairs (10GHz) and 31 reserved pins
- The protocol of the differential pairs is defined by substandards (PCIe, Ethernet are just 2 examples)
- System management based on IPMI (I2C) but only as a Device
- Backplane can have star, double-star (both requiring a switch) or mesh topology
- Backward compatible with old VME64 (2esst) boards\*
- Not many ongoing proje Device

- VXS is VITA-41
- It re-defines the P0 (middle connector) to have 16 differential pairs (10GHz) and 31 reserved pins
- The protocol of the differential pairs is defined by substandards (PCIe, Ethernet are just 2 examples)
- System management based on IPMI (I2C) but only as a recommendation
- Backplane can have star, double-star (both requiring a switch) or mesh topology
- Backward compatible with old VME64 (2esst) boards\*
- Not many ongoing projects

## VXS DSP FMC Carrier


http://www.ohwr.org/projects/vxs-dsp-fmc-carrier

- Currently being developed by the RF group of CERN
- 8 full duplex Gbit links on the VXS connector
- 2 HPC FMC mezzanines
- Foreseen to be used with a RTM



## From ATCA to uTCA

- ATCA stands for Advanced Telecommunications Computing Architecture
- ATCA is PICMG 3.X
- Boards are in 8U format
- Possibility to have RTM in 8U format with user defined connections
- Supply voltage -48V (DC-DC conversions on board) with a max of 200W per card
- Has 3 connectors' zones: Power & System management, Data Transfer (up to 5 connectors), User defined connector for rear I/O
- Up to 200 differential pairs, among which 6 dedicated to clock synchronization
- System management based on IPMI



## From ATCA to uTCA

- The Advanced Mezzanine Card (AMC) was originally a hotswappable mezzanine for ATCA carriers
- It exists in 6 form factors (all 180mm deep):
  - 74 or 149 mm wide
  - 13, 18 or 28 mm deep
- 80W per board on 12V




- 20 LVDS lanes (Eth, PCIe being the most common protocols used)
- Dedicated clock lines
- Board management based via IPMI
- It is powerful enough to be a stand alone system and so uTCA started



- Standardized in 2006 by PICMG
- Min signaling speed is 3.125 GHz
- It requires MCH board (Micro TCA Controller Hub) with up to 7 AMC per MCH
- Possibility to have redundant MCH
- Up to 8 LVDS pairs for data transfer trough the switch (fat pipes)
- Protocol not defined but Ethernet and PCIe are the most common
- In single width can have 1 FMC per board on the front panel (2 in double width)
- Each AMC need a MMC implementing IPMI







- Standardized in 2006 by PICMG
- Min signaling speed is 3.125 GHz
- It requires MCH board (Micro TCA Controller Hub) with up to 7 AMC per MCH
- Possibility to have redundant MCH
- Up to 8 LVDS pairs for data transfer trough the switch (fat pipes)
- Protocol not defined but Ethernet and PCIe are the most common
- In single width can have 1 FMC per board on the front panel (2 in double width)
- Each AMC need a MMC implementing IPMI

### Some uTCA products



- 19" rack mountable
- Dual star backplane
- Up to 10 AMCs
- External AC->DC PSU required



- 19" rack mountable
- 8 full size and 4 compact size AMC slots
- For 3<sup>rd</sup> party power supply modules



- 2U / 19" chassis
- Slots for up to 12 AMCs
- Cooling dimensioned for 40W per slot



- MCH
- Fat-pipe mezzanines for:
  - PCle
  - 10GB-Eth
  - Serial RapidIO
  - Clocks
- 6 mid size (single or double width) AMCs
- AC or DC PSU
- Single star backplane

#### Slide from Markus Joos (CERN) 14/17

### Some uTCA products



Some interoperability issues have been noted between products from different vendors due to 'grey zones' in the IPMI Standard

#### https://twiki.cern.ch/twiki/bin/view/XTCA/WebHome

- 19" rack mountable
- 8 full size and 4 compact size AMC slots
- For 3<sup>rd</sup> party power supply modules



- 6 mid size (single or double width) AMCs
- AC or DC PSU
- Single star backplane

#### Slide from Markus Joos (CERN) 14/17


- PCle
- 10GB-Eth
- Serial RapidIO

Clocks

# MTCA.4 (uTCA for Physic)

- Under ratification process
- Reduce a bit the freedom of uTCA to simplify and standardize the use of synch signals
- PCIe is the strongly reccomended protocol for the communication
- It introduces the possibility to have an RTM of the same size (MTCA + RTM adds up to a real estate of about 125% of a 6U VME board)

## MTCA.4 example



- Carrier for 1 FMC
- 4 SFP on the front panel
- Many ongoing RTM designs

### http://tesla.desy.de/doocs/doocs.html

## So many options....

- Which one to choose may depend on technical or historical reasons
- Try to communicate, even if we are using different busses we can still share alot
- Dropping a bit of freedom we might end up with more synergies: try to share your design and be ready to get external inputs/ requirements
  - the Open Hardware Repository (<u>www.ohwr.org</u>) is a good place to start
- Most systems are based on FPGAs.
  - Lets try to use the same architecture: the use of the same internal bus simplify code exchange
  - Lets try to use as much as possible free and vendor independent modules (www.OpenCores.org)

## So many options....

- Which one to choose may depend on technical or historical reasons
- Try to communicate, even if we are using different busse
- ..., the second we might the second s

internal bus simplify code exchange

Lets try to use as much as possible free and vendor independent modules (www.OpenCores.org)