



# Design and test of an Accelerator Driven Neutron Activator at the Joint Research Centre of the European Commission

K. Abbas, G. Cotogno, N. Gibson, U. Holzwarth and F. Simonelli

Institute for Health and Consumer Protection, Joint Research Centre, European Commission, Ispra (VA), Italy

S. Buono and L. Maciocco

Advanced Accelerator Applications (AAA), St. Genis Pouilly, France

R. Rocca

European Organisation for Nuclear Research (CERN), France/Switzerland

N. Burgio ENEA, Casaccia, Italy

G. Mercurio

ENEA, Ispra, Italy

18<sup>th</sup> International Conference on Cyclotrons and their Applications 2007





# **Outline**

- Ø ARC concept and previous experiments
- $\emptyset$  Motivation the INBARCA project
- $\varnothing$  New design for an ARC neutron activator
- $\ensuremath{\varnothing}$  Installation and preliminary results
- $\varnothing$  Concluding remarks







## **Adiabatic Resonance Crossing (ARC) concept**

- ARC was introduced by C. Rubbia for transmutation and radioisotope production (by neutron capture)
- The ARC method consists of moderating neutrons in lead
- Pb has the lowest capture cross section in the fast neutron field



- In Pb fast neutrons are moderated in small energy degradation steps therefore neutron capture in the epithermal range (resonance range) is enhanced







## Use of ARC Concept for Transmutation or Radioisotope Production

- 1 Fast neutrons are generated in a target bombarded with accelerated charged particles
- 2 Then they are incrementally slowed by scattering with relatively little energy absorption in lead down to the resonance energy range of the material to be transmuted
- 3 Finally, they are captured in the material to be transmuted (neutron captures take place)





# Transmutation by Adiabatic Resonance Crossing (TARC) Experiment at CERN (1996-1999)

- 1 Facility installed in the CERN PS proton beam line
- 2 Neutrons produced by spallation with proton beam (2.5-3.5 GeV)
- 3 Neutrons slowed down in Lead (3.3 m x 3.3 m x 3 m, ~ 334 tons)
- 4 TARC Conclusions:
  - ARC can be used to transmute large amounts of <sup>99</sup>Tc or <sup>129</sup>I (long lived f. products)
  - ARC can be used as an alternative method (alternative to nuclear reactors) for radioisotope production for medical or other applications





## ARC experiment at the Cyclotron of Louvain-La-Neuve (Belgium)

- 1 Aim: Feasibility study for industrial production of <sup>99</sup>Mo (generator of <sup>99m</sup>Tc) and <sup>125</sup>I using the ARC concept in a cyclotron (University of Louvain)
- 2 Neutron generated by proton beam (65-75 MeV) bombarding Be target
- 3 Neutron slowing down in pure lead (1.6 m x 1.6 m x 1.63 m, 47 tons)
- 4 Conclusion: The results were very encouraging and seem to confirm that the ARC concept can be used for radioisotope production for nuclear medicine





## Aim of the current project

- partially funded by the EUREKA programme, project INBARCA -(Innovative Nanosphere Brachytherapy by Adiabatic Resonance Crossing with Accelerators)

- 1 Test of a new ARC design concept at low energy (Cyclotron)
- 2 Measurement of activation yields and validation of MC calculations
- 3 Activation of nanoparticles for Brachytherapy (Ho and Re)
- 4 Investigation of other potential uses (other radioisotopes, activation of nanoparticles for tracer studies, etc.)





8

Giardini-Naxos, Italy, 30 September - 05 October 2007, Cyclotrons 2007 Conference

# List of radioisotopes used in brachytherapy (in black) and the ones proposed in this project (in red)

Radioisotope	Symbol	T <sub>1/2</sub> (h)	Decay mode	Mean energy	Current production method	Main applications
125-Iodine	<sup>125</sup> I	1425.6	е	35 keV	Reactor	Prostate cancer
103-Palladium	<sup>103</sup> Pd	407.76	ec	21 keV	Reactor & Accelerator	Prostate cancer
90g-Yttrium	<sup>90g</sup> Y	64.104	b-	930 keV	Reactor	Live cancer
192g-Iridium	<sup>192</sup> gIr	1771.92	b-(95.24%) b+(4.76%)	317 keV	Reactor	HDR brachytherapy
188g-Rhenium	<sup>188</sup> g <b>Re</b>	16.98	b-	2 MeV	Reactor	Bone cancer, rheumatoid arthritis, prostate
186g-Rhenium	<sup>186g</sup> Re	89.25	b-	1 MeV	Reactor	Bone cancer, rheumatoid arthritis, prostate
166-Holmium	<sup>166</sup> Ho	26.80	b-	2 MeV	Reactor	Liver Tumour





## New design for an ARC neutron activator







## **System design: calculations**

#### MCNPX, FLUKA and STAR-CD codes were used for designing the new ARC facility

Components taken into account in the simulations:

- Be target (quality, thickness, shape)
- Proton irradiation (energy, charge, shape)
- The cooling water of the Be target (shape, flow)
- The lead buffer and Graphite reflector (quality, shape)
- Irradiation channels (positions)



The final design was optimised for maximum activation yield (with thermal and epithermal neutrons) of Ho and Re in the irradiation channels





## JRC Cyclotron (Ispra, Italy)

Particles	Minimum Energy (MeV)	Maximum Energy (MeV)	Maximum Extracted Current (mA)
р	8	40	60
а	8	40	30
<sup>3</sup> He <sup>2+</sup>	8	53	30
d	4	20	60





RF cavities	2, lombda/4		
Dees	2, 90 degrees		
Beam aperture	20 mm		
Tuning	Moving shorts/trim cap.		
RF range	12.5 –27 MHz		
Frequency stability	< 10-6		
Amplitude stability	< 10-3		
Max. Dee peak voltage	44 kV		
Ion source	P.I.G. Type		
Pole diameter	115 cm		
Magnet weight	60 tons		
Main coils Max. Curr.	850 A		
Sectors	3		
Hill gap	100 mm		
Valley gap	180 mm		
Max. magnetic field	2.1 Tesla		
Extraction radius	50 cm		
Trim coils	8		
Harmonic coils	84 sets		

#### Scanditronix MC 40





## Installation of the neutron activator







Dimension: 60 cm x 60 cm x 60 cm Weight: ~ 600 kg





## **Control system of the neutron activator**







# Preliminary Results Activation of foils of Mo and Au







## Preliminary Results Activation of foils of Re and Ho



![](_page_15_Picture_0.jpeg)

![](_page_15_Picture_1.jpeg)

16

Giardini-Naxos, Italy, 30 September - 05 October 2007, Cyclotrons 2007 Conference

## **Preliminary Results Summary**

Radioisotope	T <sub>1/2</sub>	Reaction	Yield (MCNPX)	Yield Measured (Ispra)	Yield Measured (LLN)
<sup>198</sup> Au		<sup>197</sup> Au(n,g) <sup>198</sup> Au	553.83		
<sup>196</sup> Au		<sup>197</sup> Au(n,2n) <sup>196</sup> Au	1.99		
<sup>198g</sup> Au	2.69 d	<sup>197</sup> Au(n,g) <sup>198g</sup> Au		724.20	194.46 * (526.99 **)
<sup>196g</sup> Au	6.2 d	<sup>197</sup> Au(n,2n) <sup>196g</sup> Au		1.58	
<sup>24g</sup> Na	14.96 h	<sup>27</sup> Al(n,α) <sup>24g</sup> Na		5.37	
<sup>99</sup> Mo	66 h	<sup>98/100</sup> Mo(n,g/2n) <sup>99</sup> Mo		7.13	1.85 * (5.02 **)
<sup>166</sup> Ho		<sup>165</sup> Ho(n,γ) <sup>166</sup> Ho	1650.00		
<sup>166g</sup> Ho	26.8 h	<sup>165</sup> Ho(n,g) <sup>166g</sup> Ho		2520.00	
<sup>186</sup> Re		<sup>185</sup> Re(n,γ) <sup>186</sup> Re	693.00		
<sup>188</sup> Re		<sup>187</sup> Re(n,γ) <sup>188</sup> Re	1150.00		
<sup>186g</sup> Re	3.7 d	<sup>185/187</sup> Re(n,g/2n) <sup>186g</sup> Re		385.00	
<sup>188g</sup> Re	0.71 d	<sup>187</sup> Re(n,g) <sup>188g</sup> Re		2100.00	

\*Yield corrected for proton energy bombardment, \*\* Yield for 65 MeV proton energy as published (LLN),

• Yield unit: kBq/( $\mu$ A.h.g), Measured yield uncertainties: < 10%

![](_page_16_Picture_0.jpeg)

![](_page_16_Picture_1.jpeg)

![](_page_16_Picture_2.jpeg)

## Conclusions

1 - A new concept of an ARC neutron activator was designed and tested. With respect to previous designs it is much more compact ( $60 \times 60 \times 60 \text{ cm}^3$ , weight ~ 600 kg)

2 - Preliminary results on activations of foils of various materials were in good agreement with calculations

3 - With reference to previous work, slightly higher production yields of <sup>99</sup>Mo (generator <sup>99m</sup>Tc) and <sup>198g</sup>Au were obtained (factor ~4)

4 - The promising activation yields accomplished in this work open interesting perspectives for brachytherapy studies using Ho and Re based radioactive nanoparticles

5 - The ARC activator developed in this work may constitute an attractive alternative to nuclear reactors for production of certain radioisotopes for medical or other applications

![](_page_17_Picture_0.jpeg)

![](_page_17_Picture_2.jpeg)

18

# THANK YOU FOR YOUR ATTENTION