

# STABILIZING THE BEAM CURRENT SPLIT RATIO IN TRIUMF's 500 MeV CYCLOTRON WITH HIGH LEVEL, CLOSED-LOOP FEEDBACK SOFTWARE

J.J. Pon, K.S. Lee, M.M. Mouat, T. Planche, P.J. Yogendran TRIUMF, Vancouver, Canada

In the pursuit of progressively more stable beam currents at TRIUMF's 500MeV cyclotron there was a proposal to regulate the beam current split ratio for two primary beam lines with closed-loop feedback. Initial runs have shown promising results and have justified further efforts in that direction. This paper describes the software to provide the closed-loop feedback, and future developments.

### INTRODUCTION

- Three beam lines are presently in use but there are plans for a new fourth beam line
- Extracting multiple beams is relatively straight forward
- Stabilizing the beam currents in multiple beam lines is challenging
- Rare isotope production requires stable beam current:
  - Too much beam over-heats the target
  - Too little beam produces much less isotopes
- Cycling the beam on and off ages the target
- Closed-loop feedback has been used for more than 8 years for single beam line current stability and position stability
- Current stability existed, using an electrostatic deflector for only one beam line but decreased stability on other beam lines
- A proposal to stabilize the split ratio of two beam lines using a harmonic coil was advanced
- The suggestion uses a Bz magnetic field to alter the split ratio of the two extracted beams


#### BEAM CURRENT ADJUSTMENT BY HARMONIC COIL

- The cyclotron accelerates H- and uses stripping foil extraction to extract protons - Trim and harmonic coils exist to alter the beam path of the H- as it spirals out
- The coils provide radial (Br) and vertical (Bz) magnet field components, which move the
- beam vertically and radially (horizontally) respectively - The ratio of the currents extracted is determined primarily by the relative position of the
- circulating/accelerating beam to the position of the two extraction foils - By moving the beam horizontally using the Bz, current can quickly be re-positioned from
- one foil to the other
- The harmonic coil is a virtual device comprising six power supplies and related coil windings
- A separate process monitors two extracted currents and calculates the split ratio
- The feedback loop software adjusts the beam position to stabilize the split ratio

#### DEVICE IMPLEMENTATION

- There are thirteen sets of harmonic coils
- Each set comprises six pairs of coils located in a 6-fold symmetrical manner in the cyclotron
- They are used to adjust the local magnet field at a particular radius
- Harmonic coil 13 is the outermost set and was chosen for use in the split ratio stability program
- There are six parameters for this harmonic coil:
  - The 1st harmonic amplitude for Br and Bz
  - The 1st harmonic phase for Br and Bz
- The 3rd harmonic amplitude for Br and Bz Each parameter is implemented as a virtual device

#### ION PROGRAM FEATURES/USER INTERFACE - Application program reads the split ratio, compares it to the target value and adjusts the Bz (horizontal beam position) if necessary - User interface has three parts: • Summary control and monitoring page for stability program Detailed control and monitoring page for virtual devices Control from the main console - State changes and user changes to parameters are automatically recorded in the master log View Commands Options Print BEAM SPLIT RATIO STABILITY PROGRAM - HARMONIC COIL 13 Page 3HS (HELP) **ENABLED** Pulser Program (5P) PULSER PULSER Curr Stability Prog (2AS) ENGAGED **PROGRAM** PROGRAM Posn Stability Prog (2AP) ENGAGED DISABLE **ENABLED** F1 F2 SPL RATIO SPL RATIO Split Ratio Stab. Prog ENGAGED Split Ratio **STABILITY** STABILITY Present 0.9180 DISABLE ENABLED Desired 0.9180 1st Amplitude 11.0(0-1)F3 F4 10.90 2A CURRENT 2A CURRENT 1st Phase 3rd Amp Max allowable 1st Amp. 20.00 **STABILITY** STABILITY Mux -59.9 -109.3ENABLED DISABLE 0.00 Dac -60.00 Min allowable 1st Amp. -109.32F5 F6 Desired -110.00USE PRESENT # of samples to average -60.00 ° SPLIT RATIO (-180 - 180) (-120 - 120) AS DESIRED Inter-sample time (.07-1) 0.07 S eedback Gain (-100 - 100) 10.00 F8 F7 Spl Ratio Active Zone ± 0.2000 USE PRESENT Spl Ratio Dead Zone ± 0.0005 STOP AMP & PHASE (0.0 - 1.0)AS DESIRED F10 F9 BL1 adjusted foil current 110 uA BL2A adjusted foil current 9.81 uA Watchdog 392747 Sep 23 2013 12:27:02 History | List Up | List Down | Prev page | Sub Index | Main Index Enter page:



XTpage - Control and monitoring of the stability program

### PLANS FOR ENHANCEMENTS

- Install higher resolution DACs to improve control
- Improve software algorithms
- Use the pulser to stabilize the injected current

## SUMMARY

- Increased beam current stability has been achieved
- Split ratio stability software is now used in normal operation
- User interface and closed-loop application are well accepted by Operations
- Reliable operation over the last year
- Operation of the Cyclotron is easier because less Operator intervention is needed
- Further enhancements are anticipated