



Non-destructive Inspections for SC Cavities


Y.Iwashita, Y. Fuwa, M. Hashida,
K.Otani, S. Sakabe, S.Tokita, H.Tongu,
Kyoto U., Uji, Kyoto, JAPAN
H. Hayano, K.Watanabe, Y.Yamamoto,
KEK, Ibaraki, JAPAN

HiRes Cavity Endoscope : So called Kyoto Camera


CavCam3 for SPL Cavity




Former Illumination



Enhanced Illumination



New version for large cavity: (Armadillo Illumination)




14 chips/line x 2 lines/strip
x 10 strips/side x 2 sides
= 560 chips!

- Enhanced Illumination for larger surface
- Better lens for longer work distance.





3 LED's/chip!


High Density T-map & X-map




StiffenerX-map




XT-map PCB



Connection Layout






Input: PS(+5V, 0V, -5V), Clock, Reset, GND
Output: XT-map (2 x 9) , SX-map (1)
of Cables : 25




Installation


High Resolution Eddy Current Scan




Test Holes on Nb Sheet




[2643-1-1.jpg](#)



[2643-1-2b.jpg](#)




[2643-4-2.jpg](#)




Differential probe
0.3x0.25mm with sharp tip

ASWAN JSAID-3X200



Ch.1(I) 1MHz




Ch.2(Q)
ø100μm x 50μm depth





X-ray Transmission Imaging




Laser Induced X-ray Experiment



Laser Parameter	
Wave Length	800nm
Pulse Duration	130fs
Laser Energy	300mJ
Spot Size	3um (FWHM)






Laser Induced X-ray Experiment




Targets (Zr, Ag) with relatively low atomic number show good result. Defect can be observed, but its contrast is not enough for the tiny void inspections.


Possible Configuration




neutron CT imaging



ø0.5 Tungsten Carbide



No hole




ø1.5 hole


Local Micro-Grinder

Local grinding example


after 2nd V.T.




grinding by hand




machine grinding



finish



MHI-010



Yasuchika Yamamoto

evolution of grinding @Cell #1

