

CRYSTAL COLLIMATION STUDIES AT THE TEVATRON ~ T980 ~

N.V. Mokhov, G.E. Annala, A. Apyan, R.A. Carrigan, A.I. Drozhdin, T.R. Johnson, A.M. Legan,
R.E. Reilly, V. Shiltsev, D.A. Still, R.J. Tesarek, J. Zagel, FNAL, Batavia, IL 60510, U.S.A.

S. Peggs, BNL, Upton, NY 11973, U.S.A.

V. Previtali CERN, Geneva and EPFL, Lausanne Switzerland

R.W. Assmann, S. Redaelli, W. Scandale, CERN, Geneva, CH-1211, Switzerland

S. Shiraishi, Univ. of Chicago, Chicago, IL 60637, U.S.A.

Y.A. Chesnokov, I.A. Yazynin, IHEP, Protvino, Moscow Region, RU-142284, Russia

V. Guidi, INFN-Ferrara, Italy

M. Prest, INFN-Insubria, Italy

Y.M. Ivanov, PNPI, Gatchina, Leningrad Region, RU-188300, Russia

OUTLINE

☐ Introduction

- ☐ The crystal collimation concept
- ☐ The past experiences

☐ T980

- ☐ The experimental layout
- ☐ The crystal
- ☐ End Of Store (EOS) studies
 - ☐ Angular and collimator scans
 - ☐ Experimental and simulation results


☐ Crystal collimation for Collider Stores Results

☐ Conclusions

INTRODUCTION


- Bent-crystal channeling is a technique with a potential to increase the beam-halo collimation efficiency at high-energy colliders.

standard collimation



Use the crystal to drive the beam halo deep into a secondary collimator/absorber


crystal collimation



- Coherent deviation of the primary halo
- Larger collimation efficiency
- Reduced tertiary halo

PAST EXPERIENCE

- A bent crystal for beam halo collimation was first suggested for the **SSC**.
- Beam studies of crystal collimation were conducted at **IHEP** and **RHIC**
- followed by beam studies at the **Fermilab Tevatron**...
...which ultimately became the **T-980 experiment** -
the first crystal collimation experiment in realistic conditions
of a TeV hadron collider.



THE EXPERIMENTAL SETUP

In 2008, the T-980 hardware was substantially improved

goniometer:

upgraded to fix angular motion, vibration and dragging problems.

Angular resolution
 $\sim 2 \mu\text{rad}$

beam diagnostics:

Pin diode: measures the total inelastic interactions at the crystal



BLM: it measures the total losses at the collimator

Scintillating paddles: gated counters for losses at the collimator - discriminate between bunched and abort gap beam.

THE CRYSTAL

- Si crystal, 111 orientation
 - O-shaped technology
 - Full channeling angle **410 μrad**
 - Miscut angle $\theta_{\text{mis}} = 1.6 \text{ mrad}$
- “positive” orientation:

crystal planes
 θ_{mis}



Crystal Courtesy of IHEP, Protvino


Valentina Previtali

TWO MAIN RESULTS

Crystal angular scan: →


Particle response depends on the angle between the incident particles and the crystal planes.

Purpose: find the crystal channeling angle.





TWO MAIN RESULTS

Crystal angular scan:



Particle response depends on the angle between the incident particles and the crystal planes.

Purpose: *find the crystal channeling angle.*



Collimator position scan:

fix the crystal angle and change the horizontal position of the collimator.



Purpose: *measure the displacement of the channeled beam from the beam envelope.*

TWO BASIC QUESTIONS

Crystal angular scan: 

Why is the channeling width larger than expected?

10 urad (predicted) \rightarrow 100 urad (measured)



Collimator position scan:

Why is the observed displacement of the channeled beam at the collimator less than expected?


9.5 mm(predicted) \rightarrow 7 mm (measured)

TWO HYPOTHESES


1. Off momentum particles:

Particles with different energies have different impact angles

$$x' = -\frac{\alpha}{\beta} \cdot x_c + \left(\frac{\alpha}{\beta} \eta + \eta' \right) \cdot \frac{\Delta p}{p}$$

 **nominal angle** **linear dependency on momentum offset**

The angular spread is only 1.2 μrad (vs. 100 μrad observed)



2. Miscut angle:

In the crystal angular scan over the bending angle region of 410 μrad , **there is always an impact parameter region where the particles are channeled with a reduced deflection angle.**

ONE SOLUTION!

1. Off momentum particles:

Particles with different energies have different impact angles


$$x' = -\frac{\alpha}{\beta} \cdot x_c + \left(\frac{\alpha}{\beta} \eta + \eta' \right) \cdot \frac{\Delta p}{p}$$

nominal
angle

linear dependency from
momentum offset

Th **partial channeling:
different kicks for
different orientations!**


.2 μ rad (vs. 100 μ rad observed)



2. Miscut angle:

In the crystal angular scan over the bending angle region of 410 μ rad, **there is always an impact parameter region where the particles are channeled with a reduced deflection angle.**

TWO VALIDATIONS




I. Experimental


✓ collimator scans at different crystal angles reveal different channeling kicks.

✓ a linear dependence is verified

**partial channeling:
different kicks for
different orientations!**



TWO VALIDATIONS



2. Simulation

- ✓ Monte-Carlo simulations with CRYAPR and STRUCT reproduce the linear dependency
- ✓ Simulations show that $\theta_{\text{mis}} > 100 \mu\text{rad}$ affects the distribution only if the orientation is “positive”

**partial channeling:
different kicks for
different orientations!**

CRYSTAL COLLIMATION IN COLLIDER STORES

Crystal collimation has been used during collider stores beginning in March 2009.

- ☒ A successful automatic insertion test of crystal has been achieved.
- ☒ A reduction of ring losses was reproducibly observed along with local loss effects on the collimator due to crystal channeling.
- ☒ No adverse effects were found.
- ☐ In the first store a problem appeared - the crystal angle drifted by approximately 90 μ rad, due to heating from a nearby high-current bus ...
- ☒ but was fixed with angular feedback software.

A more quantitative analysis will be conducted in the fall of 2009.

CONCLUSIONS

- ✓ Crystal channeling has been observed.
- ? Measurement results did not agree with expectations - the origin of discrepancies was investigated
- ✓ both measurements and simulations confirm the significance of the **large miscut angle** (1600 μ rad).
- ✓ Simulations set a **maximum acceptable miscut angle of (plus) 100 μ rad**
- ✓ After reproducible end of store performance, crystal collimation was used **during physics store** with promising results.
- ✓ Preliminary results suggest that **two-stage cleaning** with the crystal as primary collimator is effective.

NEW HARDWARE AND FUTURE PLANS

- ▶ New hardware installation:

In the summer 2009 the O-shaped ***crystal will be replaced with a new one*** with a much smaller miscut angle and a negative orientation.

In addition, a ***second (vertical) goniometer with two alternating crystals*** will be installed: an O-shaped crystal (to exploit channeling) and a multi-strip array (to exploit volume reflection). Improved beam diagnostics will be installed.

- ▶ In the fall of 2009, Tevatron ***beam studies will start for two-plane beam cleaning*** aimed at observing convincing reproducible loss reduction in the superconducting ring and the CDF/D0 detectors



THANKS!



special thanks to


Rogelio Tomas Garcia, Guillaume Robert-Demolaize, Emanuele Laface, Thomas Weiler, Chiara Bracco, Guido Sterbini
... for their technical (and not only) support

and THANK YOU FOR YOUR ATTENTION




STANDARD VS CRYSTAL COLLIMATION





THE EXPERIMENTAL SETUP

standard collimation system



THE EXPERIMENTAL SETUP

crystal collimation system