

INFLUENCE OF THE COOLDOWN AT THE TRANSITION TEMPERATURE ON THE SRF CAVITY QUALITY FACTOR

Oliver Kugeler, Julia Vogt, Jens Knobloch

SRF 2013 Paris, France

Introduction

- Many new accelerator applications require CW SRF. Focus shifts to dynamic losses.
- Cryogenics = cost driver
- Minimize cryogenic load $P_{diss} \sim R_{surf} E_{acc}^2$
 - Want low surface resistance at moderate gradients
- $R_{surface} = R_{BCS}(f, T) + R_{residual} (?)$
- We found that cavity cooldown procedures have an impact on R_{res}
 - presumably due to the generation of additional flux from thermo currents


Introduction

- Many new accelerator applications require CW SRF. Focus shifts to dynamic losses.
- Cryogenics = cost driver
- Minimize cryogenic load $P_{diss} \sim R_{surf} E_{acc}^2$
 - Want low surface resistance at moderate gradients
- $R_{surface} = \underbrace{R_{BCS}(f, T)}_{\text{physics}} + R_{residual} (?)$
- We found that cavity cooldown procedures have an impact on R_{res}
 - presumably due to the generation of additional flux from thermo currents

Introduction


- Many new accelerator applications require CW SRF. Focus shifts to dynamic losses.
- Cryogenics = cost driver
- Minimize cryogenic load $P_{diss} \sim R_{surf} E_{acc}^2$
 - Want low surface resistance at moderate gradients
- $R_{surface} = \underbrace{R_{BCS}(f, T)}_{\text{physics}} + \underbrace{R_{residual} (?)}_{\text{originates to great fraction from trapped vortices (incomplete Meissner effect)}}$
- We found that cavity cooldown procedures have an impact on R_{res}
 - presumably due to the generation of additional flux from thermo currents

Flashback to SRF 2009



Kugeler, O. „Manipulating the Intrinsic Quality Factor by Thermal Cycling and Magnetic Fields”, TUPPO053, Proc. SRF 2009


Flashback to SRF 2009




- Measured Q increase upon “thermal cycling” to about 40 K
- Effect not understood back then. New investigations have yielded an explanation: thermocurrents

Q_0 vs T measurements



- HoBiCaT test facility used
- Horizontal, fully equipped industrial cavity welded into Helium tank
- Configuration like in accelerator module
- Temperatures down to 1.5 K
- All measurement done with one cavity in one measurement run!
- Double magnetic shielding (warm shield + cryoperm)
Small residual fields $< 1 \mu\text{T}$
- TTF-III coupler, near critical coupling ($0.8 < \beta < 2.5$)
- Verification of RF measurements with LHe-loss measurements and Lorentz detuning
Error assumed smaller than 10%




Cavity cooldown procedure



Initial cool down




Materials interfaces in cavity with tank







Thermocurrents

- Cavity forms thermoelement
- Different Seebeck coefficients for Nb and Ti





$$U_{\text{thermo}} = (S_{\text{Niobium}} - S_{\text{Titanium}}) \cdot \Delta T$$



Cycling temperature profiles



Cycling temperature profiles




Temperature difference between cavity ends when one end is making transition




Generated temperature differences between 5 K and 90 K


Surface resistance measurements




Surface resistance measurements




Surface resistance measurements



Surface resistance measurements




Results



Clear increase of R_{res} with ΔT

Initial cool down (very different temperature profile due to LHe filling from bottom)
→ difficult to “compare apples with oranges”

Results




Clear increase of R_{res} with ΔT

Initial cool down (very different temperature profile due to LHe filling from bottom)
→ difficult to “compare apples with oranges”

Lowest limit achieved
Residual resistance due to other mechanisms or ambient magnetic field

Results




Clear increase of R_{res} with ΔT

Initial cool down (very different temperature profile due to LHe filling from bottom)
→ difficult to “compare apples with oranges”

Lowest limit achieved
Residual resistance due to other mechanisms or ambient magnetic field

Results



Clear increase of R_{res} with ΔT

Initial cool down (very different temperature profile due to LHe filling from bottom)
 → difficult to “compare apples with oranges”


Lowest limit achieved
 Residual resistance due to other mechanisms or ambient magnetic field

$$U_{thermo} = (S_{Niobium} - S_{Titanium}) \cdot \Delta T$$

U_{thermo} drives thermocurrent and thus generates extra ambient field

Discarded reasons for R_{res} variation

| Hypothetical reasons for the improvement of R_{res} | Not the reason here because |
|-------------------------------------------------------|--------------------------------------|
| surface morphology | same cavity |
| RRR | |
| crystallinity, granularity | |
| total hydrogen content | |
| systematic differences | measurement taken in same run |
| calibration errors | |
| magnetic shielding efficacy | shield μ_r constant |
| adsorbate removal | process irreversible |
| Q-disease | never leads to decrease of R_{res} |



Chronological order of measurements

| Procedure | R_{res} (n Ω) | ΔR_{res} | ΔT |
|-----------|-------------------------|------------------|------------|
| Cooldown | 11.7 | | 150 |
| Cycle 1 | 6 | decrease | ~5.5 |
| Cycle 2 | 5.6 | decrease | ~5.5 |
| Cycle 3 | 13.9 | increase | 90 |
| Cycle 4 | 5.4 | decrease | ~5.5 |
| Cycle 5 | 5.5 | increase | ~5.5 |
| Cycle 6 | 7.2 | increase | 45 |
| Cycle 7 | 5.5 | decrease | ~5.5 |
| Cycle 8 | 9.6 | increase | 67 |

Change in R_{res} reversible

Conclusion and outlook

- Improve **residual resistance** by thermal cycling
- Factor of 2 improvement **and reduction** is demonstrated **depending on cycling conditions.**
- Thermocurrents most plausible explanation **as a source of additional magn. flux that is trapped during the SC transition.**
- Implement additional step in standard cavity cooldown procedure.
 - **Pause cooldown a little above T_c long enough to reach thermal equilibrium (presumably > 12 hours)**
 - **Alternatively, introduce additional short thermal cycle above T_c .**
- Implemented in HoBiCaT procedure, but cryoplant currently down so that tests have not yet been possible.