

Injection Foil Temperature Measurements at the SNS Accelerator



W. Blokland

N. Evans

C. Luck

A. Rakhman

SNS/RAD




*This manuscript has been authored by UT-Battelle, LLC, under Contract No. DE-AC05-00OR22725 with the U.S. Department of Energy. The United States Government retains, and the publisher, by accepting the article for publication, acknowledges that the United States Government retains a non-exclusive, paid-up, irrevocable, world-wide license to publish or reproduce the published form of this manuscript, or allow others to do so, for United States Government purposes. The Department of Energy will provide public access to these results of federally sponsored research in accordance with the DOE Public Access Plan (<http://energy.gov/downloads/doe-public-access-plan>).

ORNL is managed by UT-Battelle
for the US Department of Energy

Introduction

- The SNS uses a stripping foil to implement a charge-exchange injection scheme to accumulate beam in the ring
- A nano-crystalline diamond foil is used to strip the electrons from the H^- particles
- Current lifetime of a foil is ~ 3 months (2500 MWhr) at 1.2 MW
- We want to estimate the foil lifetime for higher beam powers, up to 2.8 MW for possible STS upgrade

→ Measure the temperature and compare to sublimation threshold (> 2100 K)




New


Used

Setup

- In the tunnel: very high radiation
 - Previous attempts over the years showed that the radiation instantly kills infrared cameras near the foil and quickly disrupts shielded digital cameras 10 meters away
- Foil conditioning
 - Nano-crystalline diamond foil changes to have graphite-like properties
- Beam spot has 2-D Gaussian shape, ~2 mm



Light on and 10% filter



Light off and 1% filter


- Analog camera in tunnel cubby hole last for several years but is not suitable for temperature measurements
- Use existing infra-structure to minimize costs

Setup

We can see the foil from the service building through a cable chase with only two mirrors

- First used to implement a digital foil video system

Path length is 40 meters with about 8 cm aperture in chase



Methods considered

- To use the chase for temperature measurements, we need to deal with the limited aperture and long path. Options:
 - Infrared camera
 - Expensive and needs very expensive telephoto lens to get constant temperature over the surface of each pixel
 - Need to know emissivity and calibration with optical elements
 - Need short exposure ($\sim 50 \mu\text{s}$)
 - Need infrared compatible optical elements (vacuum window)
 - Two-wave pyrometer
 - Emissivity does not need to be known (but needs to be constant)
 - Need two photodetectors with bandpass filters (cheap)
 - Use available amplifiers and telescope
 - Use existing vacuum window and mirrors
 - Visible light cameras with bandpass filters
 - If foil hot enough this could work (but presently not enough light)



→ We will build a two-wave pyrometer using bandpass filters, photodiodes, and amplifiers

Two-Wave Ratio Pyrometer


$$I(\lambda, \epsilon, T) = \frac{2hc^2}{\lambda^5} \frac{\epsilon(\lambda)}{e^{\frac{hc}{\lambda kT}} - 1} \quad \text{Planck radiation}$$

With Wien's approximation:


$$\begin{aligned} \text{Ratio}_{1/2} &= \frac{s_1 I(\lambda_1, \epsilon(\lambda_1), T)}{s_2 I(\lambda_2, \epsilon(\lambda_2), T)} \\ &= \frac{s_1}{s_2} \left(\frac{\lambda_1}{\lambda_2} \right)^{-5} e^{\frac{2hc^2}{T} \left(\frac{1}{\lambda_2} - \frac{1}{\lambda_1} \right)} \end{aligned}$$

With s_1 and s_2 the spectral transmission coefficients

- Don't need to know the emissivity as long as $\epsilon(\lambda_1)$ and $\epsilon(\lambda_2)$ are equal




Ratio curves




Optical elements


- Vacuum window in tunnel
- Two mirrors in tunnel
- Glass window in chase
- Telescope
- Longpass dichroic mirrors
- Bandpass filters
- Sensors
 - G10899 Indium Gallium Arsenide (InGaAs) PIN photodiode
 - Need to correct for its wavelength dependent sensitivity
 - Use with available current amplifier
 - Linear response within our range




photodiode



Optical Path: Filters & Windows




Bandpass filters



Windows


- Some vendors do not fully specify the spectral response of their filters for a broad spectral range
- We want to verify them for the spectral range of interest (0.4 μm – 1.7 μm)
- Many bandpass filters turned out to be leaking light outside their pass band




Longpass mirrors

Optical Path: Telescope

- It was extremely hard to get the absolute transmittance of the telescope due to its size and difficulties in coupling the same light to the fiber based optical spectrometers
- Small offset leads to ~100 K error
- Absolute transmittance of the telescope must be verified




Thorlabs CCS200
Spectral range: 0.2-1.0 μm
Multi-mode fiber coupling




Anritsu MS9740A
Spectral range: 0.6-1.7 μm
Single-mode fiber coupling

Optical Path: Telescope

- It was extremely hard to get the absolute transmittance of the telescope due to its size and difficulties in coupling the same light to the fiber based optical spectrometers
- Small offset leads to ~100 K error
- Absolute transmittance of the telescope must be verified




Thorlabs CCS200
Spectral range: 0.2-1.0 μm
Multi-mode fiber coupling




Anritsu MS9740A
Spectral range: 0.6-1.7 μm
Single-mode fiber coupling

Optical Path: Telescope

- It was extremely hard to get the absolute transmittance of the telescope due to its size and difficulties in coupling the same light to the fiber based optical spectrometers
- Small offset leads to ~100 K error
- Absolute transmittance of the telescope must be verified



Thorlabs CCS200
Spectral range: 0.2-1.0 μm
Multi-mode fiber coupling





Anritsu MS9740A
Spectral range: 0.6-1.7 μm
Single-mode fiber coupling

Optical Path: Telescope

- It was extremely hard to get the absolute transmittance of the telescope due to its size and difficulties in coupling the same light to the fiber based optical spectrometers
- Small offset leads to ~100 K error
- **Absolute transmittance of the telescope must be verified**



Thorlabs CCS200
Spectral range: 0.2-1.0 μm
Multi-mode fiber coupling



Anritsu MS9740A
Spectral range: 0.6-1.7 μm
Single-mode fiber coupling

Blackbody Source

- In April, the foil lab got a Blackbody Source
 - Up to 1000 °C
 - We used it to calibrate two optical heads:
 - 850 nm and 1600 nm with a longpass dichroic mirror at 1000 nm
 - 1000 nm and 1310 nm with a longpass dichroic mirror at 1180 nm
 - Measured at 800, 900, 1000 °C (can take hours to stabilize)



Calibrating the pyrometer in the foil lab

Blackbody Radiator


| Blackbody Temperature (°C) | Measured Ratio | Calibration (s_1/s_2) | Calibrated Ratio | Calculated Temperature (°C) | Error | Step (°C) |
|----------------------------|----------------|---------------------------|------------------|-----------------------------|--------|-----------|
| 800 | 0.181 | 0.895 | 0.162 | 799.85 | -0.02% | |
| 900 | 0.238 | | 0.213 | 901.85 | 0.21% | 102 |
| 1000 | 0.298 | | 0.267 | 1000.85 | 0.09% | 99 |

Blackbody calibration for 1000/1310/LP1180


- We obtained a calibration factor (s_1/s_2) for the optical path including sensor
 - We tested the optical heads for focus and alignment requirements for both photodiodes
 - For the optical head 850/1600, difference with the optical transmission measured was $\sim 1.8x$ ($\sim 100-150$ K)

Two-wave pyrometer


- Initial idea was to scan the foil with a motorized telescope and a pinhole in front of the photodiodes. But:
 - there was not enough light after the pinhole (unless sized 200 μm or larger)



Optical head



telescope



Projected image

- Can we collect all the light from the beam spot and still derive the peak temperature?

Beam spot blackbody radiation

- Assumptions:

- Foil has graphite-like properties with constant emissivity
- Temperature \equiv deposited energy \equiv beam intensity
- Beam is 2-D Gaussian shape about 1.6 x 1.8 mm:



$$T_G(x,y) = I_0 \cdot \exp(-x^2/2\sigma_x^2) \cdot \exp(-y^2/2\sigma_y^2)$$

- Received light is sum of different temperatures and all light is projected on the photodiode's sensitive area

→ Create new BB curve as sum of BBs at different temperatures:

$$BBS(T) = \sum_{\substack{-l < x < l \\ -k < y < k}} BB(TG(x, y))$$

Summed blackbody radiation curve




Calculated beam spot


- Summed blackbody (BBS) and for calculated beam spot (BBA)
 - Very small difference between AP calculated and 2-D Gaussian sum
 - Obtained radiation curve shifts towards longer wave lengths
- Derive new ratio curve for two-wavelength combination
 - Measure each wavelength's signal and correct for transmission

Setup in the field

- Alignment with handheld controller and camera to get the beam spot in the middle of the image
- Replace camera with optical head and test if alignment is optimal (both signals are maximized)




Photodiode signals



Pyrometer setup

Data Processing: example


- There is a lot of noise in the signals
 - data is first filtered (no phase shift: median or Savitzky-Golay filter)



Example of raw and filtered data


Data Processing: Spline Fit

- Filtered signal is still too noisy to take ratio → spline fit
 - Peak of the fits for both signals are forced to be at the same location to get better peak temperature
 - Spline fit has relaxed hinge points: spline is more flexible within the intervals




Studies: Pulse trains

- 20 pulses at 16.6 ms apart
 - Allows us to see baseline
 - Shows response of foil as it warms up
 - Shows cool down curve




Studies: Pulse trains

- 20 pulses at 16.6 ms apart
 - Allows us to see baseline
 - Shows response of foil as it warms up
 - Shows cool down curve





Studies: Pulse trains

- 20 pulses at 16.6 ms apart
 - Allows us to see baseline
 - Shows response of foil as it warms up
 - Shows cool down curve




Studies: Pulse trains

- 20 pulses at 16.6 ms apart
 - Allows us to see baseline
 - Shows response of foil as it warms up
 - Shows cool down curve




Current monitor showing 20 pulses

Data: 1000/1310




- Very similar temperatures compared to 850/1600

Data: 850/1600



- Fairly low temperature for the foil at 1450 K
 - Was about 1600 K earlier


Foil Pyrometer in the control room



Foil Pyrometer EDM Screen

- We now have a on-line prototype pyrometer

Data: Effect of foil conditioning



Foil conditioning is done by slowly raising the beam power on the foil over about half a day:

- Outgassing, conversion to graphite-like diamond, and possible sublimation
- High initial temperature: foil camera shows very bright spot, vacuum up
- For each beam power increase (blue) the temperature (red) and vacuum (green) change but recover

Foil sublimation


Equation:

$$\frac{dh(t)}{dt} \cdot \frac{1}{\rho} = -4.06 \cdot 10^8 \cdot \frac{e\left(-\frac{83500}{T}\right)}{\sqrt{T}} \quad m/s$$

S. G. Lebedev and A. S. Lebedev

(Density diamond is 3.5 g/cm³)

(Density graphite is ~2.2 g/cm³)



Example data


- Foil sublimation: integrated over time to determine dx over day
 - Foil is only 1 μm thick, can loose maybe 30%, or 0.3 μm but rate at, for example 2100K is high: 0.085 μm/day → 3 days (depending on foil density)
 - We see over months of lifetime for certain foils
 - Peak temperature should be lower than 2100 (~ 3 days lifetime)
 - Accuracy/applicability to be studied

Radiative cooling

- During beam pulse $T = T_{low} + C \cdot Beam_I \cdot dt$
- During cool off: $T = \frac{T_{pk}}{\sqrt[3]{1+3kT_{pk}^3 \cdot t}}$ with $k = \frac{2\epsilon\sigma A}{3Nk_B} = 1.82 \cdot 10^{-8}$ (At 1 μm)
- Use equation with the sum-of-blackbodies curve to calculate the measured signal


$$V_{BBS}(T, \lambda_c, \lambda_{ws}) \approx G \cdot \sum_{\substack{\lambda=\lambda_c-\lambda_{ws} \\ \lambda+=\Delta\lambda}}^{\lambda_c+\lambda_{ws}} BBS(T, \lambda) \cdot \Delta\lambda$$

- Use the measured data and iterate to determine temperature



Example curve for specific temperature

Peak temperature from cooling curve



Without using the second signal:

- Fitting to temperature: other parameters, scale and k , are held to a tight range so all variation is mapped into the temperature
- While we have estimates to calculate k , estimate scale, at this point the uncertainties are too great and too wide a temperature range can be fitted
- With using second bandpass, second optical head, more data from the foil lab, we expect to improve estimates

Summary and future


- We have installed a prototype foil temperature measurement system and started correlating temperature with foil conditioning, accelerator setup, and variations in beam parameters

- Temperature as it stand now 1500-1600 at 1.3 MW

- Accuracy?

- Signal processing: ± 100 K
- Assumptions to check:
 - No heat conduction
 - Perfect capture of beam spot light
 - Constant emissivity

- Sublimation minimal at 1500-1600 K (but we already knew this from how long a foil survives)



S. G. Lebedev and A.S. Lebedev

Summary and future

- Future Improvements

- Improve the calibration:

- Using free space optical spectrum analyzer to redo spectral measurements
 - Compare foil lab's infrared camera with pyrometer

- Improve optical head and add pinhole

- Better signal-to-noise to support 2-D temperature profiles:

- Wider bandpass filters
 - Different detectors (cooled)

- Improve optical path:

- Increase light collection: requires in tunnel optics and will be expensive
 - Reduce shimmering

- Future R&D

- With foil lab testing we hope to determine sublimation point, density, and verify emissivity measurements




Image of filament using programmable pinhole