



Outline



- Overview and requirements
- Deployment Strategy
- Status




CMS Overview



The Compact Muon Solenoid (CMS) is one of the Large Hadron Collider general purpose particle detectors

System Name	Number of PCs	Monitored Parameters
Tracker	14	350k
Calorimeter	14	115k
Muon	30	435k
Trigger DCS	2	1k
Alignment	3	3k
Services	35	20k
Total	98	934k




~ 10⁶ control system parameters



Deployment Strategy







Status




Running 24h/d

- Deployment strategy easing maintenance
 - Recovering nodes
 - Updating packages
- A hierarchy of Finite State Machines based nodes summarize states and propagates commands. The most top layer:
 - Provides control over CMS DCS trigger partitions
 - Communicates with experiment Run Control
 - Handle the handshake with the LHC



Main DCS Operator Screen








Status: HMI




- Aimed for an intuitive HMI for operators
 - No need for courses
 - No need for extensive documentation
 - Software helpers guiding operator
- Touch screen operation panels in underground cavern
 - Card reader authentication
 - Functionality enabled depending on user privileges
- 3D technology for geometrical error correlation



3D DCS View








Rack Control Touch Screens







Status: Authentication



- PVSS users and privileges are synchronized with CMS LDAP server
- Web base applications allow control group responsible to provide privileges to users
- Synchronized with CMS Shift List tool



Status: Alerts




Alarm screen summarizes all CMS DCS alerts

- Alert help engine
 - Web forms for DCS experts to add help content
 - Dynamic Web pages for Operators with incremental alert help



Alarm Screen







Status: DCS services




Central DCS services integrated

- Rack and crate control
- Gas
- Cooling
- Ventilation
- Magnet



Rack and Crate Control








Rack details








Cooling Monitoring









どうもありがとう Thank you!