

# Signal Registration Web Interface for RIKEN SPring-8


M. Celary, S2Innovation, Kraków, Poland

Toru Fukui, Toshiyuki Maruyama (RIKEN SPring-8 Center, Hyogo)


Kensuke Okada, (JASRI, Hyogo)

Kazuhide Uchida, (Cosylab Japan, Tokyo)

## • Use case scenarios



## • Registration statuses updates



ID	Requested	Accelerator	User	Type	Groups	CPU(s)	Files	New Update/ADM	WPN/CAR/ADM	STATUS	TEST Registration	PROD Registration	ACTIONS
9	2021-10-04 16:43:39	sr	test	svoc	xfel_mon	xmon-476	xvo... bit.txt	0/5/0	0/0/0	REQUESTED (Test Reg.)	2021-10-04 16:43:21		show ▾
8	2021-10-04 16:43:13	sr	test	svoc	xfel_mon	xmon-476	xvo... bit.txt	0/5/0	0/0/0	OK (Test Reg.)	2021-10-04 16:42:57		show ▾
7	2021-10-04 16:42:40	sr	test	svoc	xfel_mon	xmon-476	xvo... bit.txt	0/5/0	0/0/0	OK (Test Reg.)			show ▾
6	2021-10-04 16:42:17	sr	test	svoc	xfel_mon	xmon-xcr-03	xvo... bit.txt	15/20	8/15/30	ERR (Test Reg.)			show ▾
5	2021-10-04 16:24:24	xfel	test	svoc	xfel_mon	xmon-xcr-03	xvo... bit.txt	15/20	8/15/30	ERR (Test Reg.)			show ▾
4	2021-10-04 16:14:10	sr	dbadmin	svoc	xfel_mon	xmon-xcr-03	xvo... bit.txt	15/20	8/15/30	REJECTED (Test Reg.)			show ▾
3	2021-10-04 16:14:07	sr	dbadmin	svoc	xfel_mon	xmon-xcr-03	xvo... bit.txt	15/20	8/15/30	ERR (Test Reg.)			show ▾
2	2021-10-04 16:12:15	xfel	dbadmin	svoc	xfel_lirf	xmon-bl3-dump	xvo... bit.txt	0/0/0	0/2/0	OK (Test Reg.)	2021-10-04 16:24:01		show ▾
1	2021-10-04 15:42:29	sr	svoc	svoc	xfel_lirf	xmon-bl3-dump	xvo... bit.txt	0/0/0	0/2/0	OK (Test Reg.)	2021-10-04 16:24:34		show ▾

Showing 1 to 9 of 9 entries


## • User management



ID	Username	Email	Role	Session	Delete	Suspend
1	guest	test0@example.com	guest	None	X	
2	svoc	test1@example.com	svoc	None	X	
3	test	test2@example.com	test	None	X	
4	prod	test3@example.com	prod	None	X	
5	dbadmin	test4@example.com	dbadmin	2021-10-04 20:00:21	X	

After you change roles, reset your server to expire all active sessions.


## • Selenium test scenarios



1. Select 'SVOC' registration type.

2. Click 'File Upload' button and select 'svoc\_sample1.xlsx' file.

3. Click 'Submit' button.



**Figure 1.** Application scenarios involves multiple users and roles.

- Accelerator metadata registration
- Multiple roles scenarios
- Two databases
- Simultaneous login restrictions
- Email notifications



**Table 1.** Simplified roles table.

Action	SVOC User	TEST User	PROD User	DB admin
Max logged in accounts	-	1	1	1
SVOC check	✓	✓	✓	✓
TEST registration		✓		
TEST DB backup		✓		✓
TEST DB restore				✓
PROD registration			✓	
PROD DB backup			✓	✓
PROD DB restore				✓

- Syntax check
- New SVOC check
- Check History
- Backup & Restore
- MDAQ WEB Links

Search options ▾

All Accelerators
xfmon-bl3-dump
xfel\_llrf
All Request Users
All Types

2021/10/04
Last Update To

Search

Show 50 entries

ID	Requested	Accelerator	User	Type	Groups	CPUs	Files	New/Update/Delete	WRN/CHK/ADM	STATUS	TEST Registration	PROD Registration	ACTIONS
9	2021-10-04 16:43:39	sr	test	svoc	xfel_mon	xfmon-476	svoc.txt  bit.txt	0/5/0	0/0/0	REQUESTED (Test Regist.)			<a href="#">show ▾</a>
8	2021-10-04 16:43:13	sr	test	svoc	xfel_mon	xfmon-476	svoc.txt  bit.txt	0/5/0	0/0/0	OK (Test Regist.)	2021-10-04 16:43:21		<a href="#">show ▾</a>
7	2021-10-04 16:42:40	sr	test	svoc	xfel_mon	xfmon-476	svoc.txt  bit.txt	0/5/0	0/0/0	OK (Test Regist.)	2021-10-04 16:42:57		<a href="#">show ▾</a>
6	2021-10-04 16:25:17	sr	test	svoc	xfel_mon	xfmon-xcr-03	svoc.txt  bit.txt	15/2/0	8/153/0	ERR (Test Regist.)			<a href="#">show ▾</a>
5	2021-10-04 16:24:24	xfel	test	svoc	xfel_mon	xfmon-xcr-03	svoc.txt  bit.txt	15/2/0	8/153/0	ERR (Test Regist.)			<a href="#">show ▾</a>
4	2021-10-04 16:14:10	sr	dbadmin	svoc	xfel_mon	xfmon-xcr-03	svoc.txt  bit.txt	15/2/0	8/153/0	REJECTED (Test Regist.)			<a href="#">show ▾</a>
3	2021-10-04 16:13:57	sr	dbadmin	svoc	xfel_mon	xfmon-xcr-03	svoc.txt  bit.txt	15/2/0	8/153/0	ERR (Test Regist.)			<a href="#">show ▾</a>
2	2021-10-04 16:12:15	xfel	dbadmin	svoc	xfel_llrf	xfmon-bl3-dump	svoc.txt  bit.txt	0/0/0	0/29/0	OK (Test Regist.)	2021-10-04 16:24:01		<a href="#">show ▾</a>
1	2021-10-04 15:42:29	sr	svoc	svoc	xfel_llrf	xfmon-bl3-dump	svoc.txt  bit.txt	0/0/0	0/29/0	OK (Test Regist.)	2021-10-04 16:24:34		<a href="#">show ▾</a>

Showing 1 to 9 of 9 entries

Previous
1
Next



MDAQ Web App: Copyright(C) 2020

SPring-8 All Rights Reserved.

**Figure 2.** Fully responsive web interface. Registration statuses updates in real time. Menus and actions are role-dependant.



New SVOC check

Choose the accelerator

sr  
 xfel

SVOC files upload

Registration type	DAQ type	File	Upload
SVOC	POL/SYNC/WFM/IMG	excel/ods book	<input type="button" value="Browse..."/> No file selected.
	POL/SYNC/WFM/IMG	svoc.txt	<input type="button" value="Browse..."/> No file selected.
	POL/SYNC	bit.txt	<input type="button" value="Browse..."/> No file selected.
	WFM	array.txt	<input type="button" value="Browse..."/> No file selected.
	WFM	image.txt	<input type="button" value="Browse..."/> No file selected.
Alarm	AI/DI	excel/ods book	<input type="button" value="Browse..."/> No file selected.
	AI	almval.txt	<input type="button" value="Browse..."/> No file selected.
	DI	almbit.txt	<input type="button" value="Browse..."/> No file selected.
Priority	POL/SYN/WFM/IMG	excel/ods book	<input type="button" value="Browse..."/> No file selected.
	POL/SYN/WFM/IMG	priority.txt	<input type="button" value="Browse..."/> No file selected.

Allowed excel file sheet names: svoc, bit, array, image, almval, almbit, priority.

Options

構文チェックのみを行なう  
 SVOCチェック後に信号登録依頼を行う  
 Strict character check

MDAQ Web App: Copyright(C) 2020  
Spring-8 All Rights Reserved.

System setup

Database Info ▾

Last TEST registration: 2021-10-04 16:43:21  
Last PROD registration: None

/jmdaq\_tools/conf/paramdb.json ▾

```
{
  "sr": {
    "equip_grp": {
      "id_from": 1,
      "id_to": 1999
    },
    "sub_grp": {
      "id_from": 1,
      "id_to": 1999
    },
    "host": {
      "id_from": 1001,
      "id_to": 9999
    },
    "equip_inf": {
      "id_from": 10001,
      "id_to": 199999
    },
    "sig_inf": {
      "id_from": 10001,
      "id_to": 199999
    },
    "sig_type": {
      "id_from": 10001,
      "id_to": 199999
    },
    "wfm_type": {
      "id_from": 10001,
      "id_to": 199999
    }
  }
}
```

MDAQ Web App: Copyright(C) 2020  
Spring-8 All Rights Reserved.  
localhost:8887/system\_setup

Spring 8 Signal Registration v1.1.0beta

dbadmin ▾

Syntax check

Parameters (Test)

Parameters (Prod)

Backup & Restore

Users

MDAQ WEB Links

System

Users List

Reset passwords

Users List

Create User

MDAQ WEB Links

System

ID	Username	Email	Role	Session	Delete	Suspend
1	guest	test0@example.com	guest	None	<input type="button" value="X"/>	<input type="button" value="II"/>
2	svoc	test1@example.com	svoc	None	<input type="button" value="X"/>	<input type="button" value="II"/>
3	test	test2@example.com	test	None	<input type="button" value="X"/>	<input type="button" value="II"/>
4	prod	test3@example.com	prod	None	<input type="button" value="X"/>	<input type="button" value="II"/>
5	dbadmin	test4@example.com	dbadmin	2021-10-04 20:00:21	<input type="button" value="X"/>	<input type="button" value="II"/>

After you change roles, reset your server to expire all active sessions.

Figure 3. User UI. (a) Data upload panel. (b) Database configuration panel. (c) User management panel

## Complete system

- Data upload support for excel files
- Database configuration
- User management
- Dynamic AJAX interface




```
mateusz@mateusz-ThinkPad-E480:~/Documents/Project1 - Spring8/tornado_www$ pytest test/unit/test_accounts.py test/functional/test_login.py -v=====
= test session starts =====
platform linux -- Python 3.8.10, pytest-6.1.2, py-1.9.0, pluggy-0.13.1 -- /usr/bin/python3
cachedir: .pytest_cache
rootdir: /home/mateusz/Documents/Project1 - Spring8/tornado_website/spring8_signals
collected 6 items

test/unit/test_accounts.py::LoginTest::test_contains_form PASSED [ 16%]
test/unit/test_accounts.py::LoginTest::test_contains_inputs PASSED [ 33%]
test/functional/test_login.py::test_svoc PASSED [ 50%]
test/functional/test_login.py::test_signal_registration PASSED [ 66%]
test/functional/test_login.py::test_signal_registration_fail XFAIL [ 83%]
test/functional/test_login.py::test_database_backup_fail PASSED [100%]

===== 5 passed, 1 xpassed in 6.41s =====
mateusz@mateusz-ThinkPad-E480:~/Documents/Project1 - Spring8/tornado_website/spring8_signals$
```


```
mateusz@mateusz-ThinkPad-E480:~/Documents/Project1 - Spring8/tornado_website/spring8_signals$ python3 app.py
2021/10/04 20:12:57.728 [INFO] Clearing UserSession's...
2021/10/04 20:12:57.759 [INFO] Sessions cleared.
2021/10/04 20:12:57.772 [INFO] listening on localhost: 8887
2021/10/04 20:13:11.522 [INFO] 302 [127.0.0.1] GET / 15.11ms
2021/10/04 20:13:11.530 [INFO] 200 [127.0.0.1] GET /login?next=%2F 5.39ms
2021/10/04 20:13:11.626 [INFO] 200 GET /static/libs/css/tabulator.min.css (127.0.0.1) 2.68ms
2021/10/04 20:13:16.197 [INFO] 302 [127.0.0.1] POST /Login 72.26ms
2021/10/04 20:13:16.222 [INFO] 200 [127.0.0.1: svoc] GET /svoc_check 20.06ms
2021/10/04 20:13:16.358 [INFO] 200 GET /static/img/SPring-8.ico (127.0.0.1) 0.49ms
2021/10/04 20:13:21.284 [INFO] 200 [127.0.0.1: svoc] GET /workflow_list 75.55ms
2021/10/04 20:13:21.405 [INFO] 200 GET /static/img/SPring-8.ico (127.0.0.1) 0.58ms
2021/10/04 20:13:23.443 [INFO] 200 [127.0.0.1: svoc] POST /check_workflow_status 28.72ms
2021/10/04 20:13:23.550 [INFO] 304 [127.0.0.1: svoc] GET /svoc_check 30.26ms
2021/10/04 20:13:23.674 [INFO] 200 GET /static/img/SPring-8.ico (127.0.0.1) 0.51ms
2021/10/04 20:13:24.775 [INFO] 302 [127.0.0.1] GET /logout 43.53ms
2021/10/04 20:13:24.844 [INFO] 200 [127.0.0.1] GET /login 11.94ms
2021/10/04 20:13:31.210 [INFO] 302 [127.0.0.1] POST /Login 68.25ms
2021/10/04 20:13:31.238 [INFO] 200 [127.0.0.1: test] GET /svoc_check 19.91ms
2021/10/04 20:13:34.036 [INFO] 302 [127.0.0.1] GET /logout 19.98ms
2021/10/04 20:13:34.041 [INFO] 200 [127.0.0.1] GET /login 3.59ms
2021/10/04 20:13:34.181 [INFO] 200 GET /static/img/SPring-8.ico (127.0.0.1) 0.63ms
```



## Documentation

### Svoc Registration Logic

- SvocCheckHandler - is where the user uploads the files (svoc.txt, image.txt, etc.). POST method of this handler, performs a syntax check and saves its results to temporary file. Filename equals username -> one user = one tmp file.
- SvocCheckResultsHandler - is where the user can see the results of the syntax check, and request a signal registration (it also saves permanently a Workflow created in previous step)



## Quality Control

- Functional tests for user scenarios implemented in Selenium framework
- Unit tests for controller testing
- Concise documentation covering the most important maintenance guidelines
- Debug logs
- Work in progress...

Figure 4. Quality control. (upper left) PyTest suite (bottom left) Selenium functional tests (upper right) logger (bottom right) documentation