

Design of Split Permanent Magnet Quadrupoles for Small Aperture Implementation

I. Gadjev, G. Andonian, T. Campese, C. Hall, M. Ruelas

Poster No. MOPAB139 Presented at IPAC 2021, Virtual Edition May 24-28, 2021

Background: Ultrafast Electron Microscopy



- UEM at high energy (3 MeV) ٠
 - Reduces space charge forces in electron ٠ beam
- Strong focusing with permanent magnet quadrupoes (PMQ)
 - Provide high focusing gradients in a compact ٠ footprint
 - Since quads focus in one dimension and ٠ defocus in the orthogonal, the optic must be a multiplet to produce a round lens
- Optimization scheme arrived at a quintuplet design
 - See Chris Hall's poster (MOPAB249) for details on the multi-objective optimization algorithm (MOGA)



Wan, Chen, Zhu, Ultramicroscopy 194, 143 (2018)



Halbach, Nucl. Instrum Methods 169, 1-10 (1980)

Quintuplet design

- Optimization scheme arrived at a quintuplet design
 - See Chris Hall's poster (MOPAB249) for details on the multi-objective optimization algorithm (MOGA)
- MOGA quadrupole properties:
 - Big aperture (r~2.5mm), short length (L~2mm, and high gradients (~200T/m)
- Shown are the target gradient profile and that achieved from an engineering informed design with pyRadia (<u>https://github.com/ochubar/Radia</u>)
- The 3D magnetostatic simulations (blue line) achieve the required peak gradient
 - But produce heavier fringe tails than the target (first order Enge model – dashed line)
 - The large aperture-to-length ratio introduces large 3D effects





"Splittable" hybrid PMQ design



- In order to place the quadrupoles around the electron beam chamber a splittable design was introduced
- Steel blocks replace 4 of the PM _____ blocks
 - The steel is easily cut and allows the hybrid-PMQ to be mounted around a chamber
 - Allows the quads to remain outside of vacuum
 - Quads are removable without changing the electron beam chamber
- Peak gradient is reduced since PM volume is replaced with steel









Degradation of Harmonic Content



The introduction of steel in the design increases the non-quadrupole moments inside the aperture



Manufacture and Measurement



- RadiaBeam has manufactured the 3 different hybrid-PMQs outlined in the quintuplet optic design
- Hall probe measurements were undertaken to qualify the magnetic characteristics of the quadurpoles





Gradient Profile Measurements



- Measured gradient profiles are presented for 6 samples of hybrid-PMQ type 1
- The measured peak gradient is far below the peak gradient reached in 3D magnetostatic simulations
 - This is expected in the manufacture of such small assemblies as tolerance stackup becomes large
- The physical length of the manufactured quadrupoles is 6 mm
 - Target magnetic length was 1.5 mm with a peak of 214 T/m
- Intent is to cut the quadrupoles to size in order to achieve desired magnification and resolution from full optic
 - New MOGA optimizations are under way



Outlook



- Measurement of the quadrupole gradients will be fed back into the MOGA optimizer (C. Hall, RadiaSoft, MOPAB249) in order to produce a sensible quintuplet optic
- Assembly and self-alignment of the full quintuplet will then proceed
- Experimental runs are planned at the Brookhaven National Lab's UED facility (G. Andonian, RadiaBeam, MOPAB139)





Acknowledgements

- G. Andonian, T. Campese, M. Ruelas (RadiaBeam)
- C. Hall (RadiaSoft)
- M. Fedurin, K. Kusche, X. Yang, Y. Zhu (BNL)

• This work supported by Grant No. DE-SC0018562