

# High-Performance Thin-Film Niobium Produced via Chemical Vapor Deposition (CVD)

Ryan Porter SRF, July 19 2017 Lanzhou, China



## CVD Niobium Work at Cornell/Ultramet

- Cornell University has been testing CVD niobium created by the company Ultramet.
  - Produces CVD metals and ceramics for aerospace, medical and energy industries
- Early CVD Nb work focused on making good (pure/high RRR) samples and devising a CVD-based cavity fabrication methodology
  - Successful!
- Made full CVD niobium cavity
  - Had some fabrication issues
- RF tests of CVD sample plates



CVD niobium on molybdenum puck




## Thin Film Niobium Advantages

- Increased thermal stability
  - Nb: 75 W/m -> Cu: 300-2000 W/m
- Lower cost
  - High RRR Nb ≈ 10x price of Cu
    - CVD process uses commercially available chip Nb start materials (~\$50/pound)
  - Can avoid (reduce) expensive electron beam welding
- Decreased Flux Trapping Sensitivity
  - $-300 500 \text{ n}\Omega/\text{G} -> 1 \text{ n}\Omega/\text{G}$
- Can <u>avoid inclusions</u> caused by machining



## What is CVD?

 A substrate is exposed to one of more vapors/gasses and a reaction/decomposition takes places that leaves niobium (or other metal/ceramic) behind




Reactor diagram showing use of NbCl<sub>5</sub> to produce CVD niobium (based on diagram by P. Pizzol et al. in Proc. of IPAC 2016, Busan, Koriea, 2016)



## What is CVD?

#### How to deposit niobium?

- Common method:
  - NbCl<sub>5</sub> is vaporized
  - Hydrogen is added
  - The substrate is heated (e.g. 700 C)
    - Reaction takes place on substrate
  - Resultant gasses pumped away



Reactor diagram showing use of NbCl<sub>5</sub> to produce CVD niobium



## How does it differ from other techniques?


#### Advantages of CVD:

- Forms a metallurgical diffusion bond
  - Strong enough withstand High Pressure Rinses (HPR) and Centrifugal Barrel Polish (CBP)
  - Creates good thermal contact
- High deposition rate
  - $-300 \mu m/hour$
  - Can make both thick and thin films



## Sample Studies

- In 2012 we worked with Ultramet to test CVD niobium samples
  - Various CVD parameters (pressure, temperature, etc.)
  - Find process created good niobium
- We tested the RRR and T<sub>c</sub>
  - Found T<sub>c</sub> to be consistent with niobium
  - Found samples with RRR > 250
- CVD can make high RRR niobium!



RRR measurement system at Cornell



## **CVD Niobium Cavity**

- Ultramet produced a <u>3</u>
  GHz elliptical cavity
  - Graphite mandrel
  - Several microns of high RRR niobium
    - Layer was CNC ground
  - +3 mm of low RRR niobium
  - The niobium machined and the mandrel was removed



Graphite mandrel




Cavity after CVD process



## **CVD Niobium Cavity**

## Seamless bulk CVD niobium cavity!




CVD niobium cavity after machining



## CVD Niobium Cavity Initial Tests

- Initial tests of the cavity showed high surface resistance
  - $-R_o$  of 14  $\Omega$ m
- Surface contaminants from production
- Needs BCP






## **CVD Niobium Cavity Results**

#### After 100 µm BCP:

- R<sub>BCS</sub> as expected
- $R_0 \sim 650 \text{ n}\Omega$ 
  - Was 14  $\mu\Omega$
  - Expect <  $10 \text{ n}\Omega$
- Quench at 1.2 MV/m
  - Pits found on cavity surface
- Low mean free path
  - Contaminants from mandrel outgassing
- Machining may have damaged RF surface
- Good results!
  - Need cleaner production





## **Cornell Sample Host Cavity**

- Full cavities is harder and expensive
  - Want films instead of bulk
- Need to test CVD surfaces in SRF conditions
- The Cornell Sample Host cavity can take 5-inch sample plates
  - 3.9 GHz sample host cavity
  - Fairly uniform magnetic field over sample
  - Q of 1·10<sup>10</sup> at 2 K with niobium sample




The Cornell Sample Host Cavity



## **CVD Test Plates**

- In 2016 Ultramet made CVD niobium on Cu and Mo samples
- Multiple processes
  - Low and high temperatureCVD
- Nominally 150 200 μm thick films
- Some mechanically polished
- Plates tested "as received"





CVD niobium on copper test plate



## **Surface Cross-Section**

- Cross-section view shows a 60 μm Nb surface layer for this sample (on Cu)
- EDX line scan shows fast transition from the substrate to coating
  - Cu has not diffused far (~1 um) into Nb








## Surface Resistance


- Tested at 2 K (and other temperatures):
- Medium quench field of 50 mT
  - 12 MV/m for TESLA cavity
  - 10 times increase in quench field!
- Resistance as low as 300  $n\Omega$
- Resistance rises rapidly with increasing field






## Surface Resistance

- $R_{BCS}$  at 2 K was 100 to 300  $n\Omega$  and flat
  - Expect  $\sim$ 110 nΩ 3.9 GHz niobium
- R<sub>BCS</sub> is flat
- Best plate had  $R_o \sim 20 \ n\Omega$  at low fields
  - R<sub>o</sub> is <10 nΩ for good niobium
  - High temperature Nb on Mo plate
- $R_o$  is 200  $n\Omega$  to 50  $\mu\Omega$  for other samples









## **Surface Defects**

- Thermometry showed local heating on the sample plates
  - SEM imaging found <u>large pits and inclusions</u>
    - Chemical analysis found inclusions rich in carbon, oxygen and other elements
      - May be caused by condensation forming on roof of reactor dripping onto the sample—not a problem for cavities!





17/22



### **Potential Causes**

- Bumps, divots, and inclusions in surface
- Glow Discharge Mass Spectrometry (GDMS) of some CVD Nb on Cu plates revealed 200-400 ppm Cu on surface
  - How much is too much copper?
- Q-Disease?
  - Some CVD techniques use hydrogen
  - Previous CVD samples had a high hydrogen concentration
    - Recent plates not tested for hydrogen





## Other CVD Niobium for SRF Work



## Sample Studies

- Paolo Pizzol et al. at STFC have created Nb on Cu samples
  - used CVD and (Plasma Enhanced) PECVD
- Has successfully created several µm thick Nb thin films
  - Correct structure
  - Still low RRR









## **Beyond Niobium**

- P. Pizzol et al. have also been working on CVD of other niobium based materials.
- Successfully produced CVD NbN and NbTiN







## Conclusion

- Can create high RRR niobium on Cu
  - As good as best sputtered niobium
- Robust, chemically-bonded coatings with good thermal interfaces
- Can coat complex geometry
- Fairly low resistances
  - Best case:
    - Q  $\sim 4.5 \cdot 10^9$  at 2 K for 1.3 GHz TELSA cavity
- Achieve medium field strength
- Need to take measures to consistently minimize preventable contamination issues
- Greatly improved from early work
- CVD niobium is promising
  - Recommend further R&D

